



DANCE FLOOR MAINTENANCE

Storage and Maintenance

Floors can be cleaned using standard cleaners and mop

You should clean your floor after each use so as to prevent a build-up of dirt. Start by using a standard broom to remove loose debris and if required, use cleaners to clean any remaining dirt.

Floor sections should be stored flat on the floor, pallets, or on the Vinyl Dance Tiles transport cart. Floor sections should be stored face-to-face and back-to-back so to avoid scratching of the floor. DO NOT store sections on their side as this can damage floor sections and cause tiles to warp. Do not use your floor in direct sunlight.

Sections should be stored indoors in a climate-controlled location. Exposure to extreme temperature variations should be avoided.